

YC-RL.04.20B 4 CH 20A Relay Switch Module (With Current Detection)

#### Product Manual

Release : September 22, 2022 Version : V1.5



Firgue1.4 CH 20A Relay Switch Module (With Current Detection)




Figure 2. Dimensional Drawing - Front View Figure 3. Dimensional Drawing -Sideview






Figure 4. Product Information



operate the device

Figure 5. Fire Interface Description



### **Product Overview**

The 4 CH 20A Relay Switch Module (With Current Detection) (see Figure 1) serves as a system switch execution unit, typically installed in a distribution box. It can control the switching of lights, the on/off state of devices, the on/off state of passive dry contacts, the opening and closing of strong or weak current curtains, the hot/cold valve of water-cooled air conditioning, and the switching between high/medium/low fan speeds.

#### **Function Description**

- Standard 35mm DIN rail installation: Occupies 4P module units.
- Equipped with Fanhua single contact magnetic latching relay, providing 4-channel 20 A relay switching.
- Each circuit can independently control devices up to 4400W
- Supports setting the initial power-on state for each circuit (on, off, or previous power state). •
- Features sequential delay startup for multiple circuits to prevent power grid surges from simultaneous startup.
- Support current mA/ voltage V/ power W instantaneous detection, power can be accumulated detection unit Kw.h •
- Returns the actual switch status of each circuit to the monitoring center immediately after executing scene commands.
- Equipped with mechanical strong cut off function, equipment networking failure or power off, the relay can also turn on and off
- Includes a fire protection interface with one normally open passive and one active 24V connection.
- Supports online firmware updates and Bus network disconnection alarm function.
- Supports RS485/YC-BUS communication.

#### **Precautions**

- Use CAT5E or RVV4\*0.75 four-core wire for bus wiring.
- After installation, check all connections to ensure they are correctly connected.
- The current for each output circuit must not exceed 20A.
- To protect the equipment and load, it is recommended to connect a 20A circuit breaker for each circuit.

### **Product Information**

Product Dimensions: See Figures 2 and 3

Product Wiring: See Figure 8

Product Information: See Figure 4

- Relay Output Wiring Terminals: Use a one-in-one-out method; the hole diameter can accommodate 4 square mm wire. 1. 2
- LED Indicators
- Power : Power indicator light.
- Bus: Network indicator light; steady on indicates normal network connection, slow blinking indicates abnormal . network connection.
- Function Keys: Forced Cut-off Switch (See Figure 13): A-D corresponds to channels 1-4. Use a small flathead screwdriver to toggle the switch up and down in the groove.
- 3 Bus Interface: 24V, G, A, B. 4.
  - Setting Address:
- Step 1: (See Figure 8) Remove the latch cover; it requires some force to pull it out.
- Step 2: (See Figures 6-7) Refer to the address setting dip switch table to set the dip switch to the corresponding address.
- Step 3: After setting the address, remember to replace the latch cover.
- Fire Interface:(see Figure 5). 5.

Note: The module has a built-in induction coil to detect the instantaneous current of 1-4 circuits.

## **Product Installation**

See Figures 9-12

- Step 1. Secure the 35mm rail with screws.
- Step 2. Remove the snap-on cover from the 4 CH 20A Relay Switch Module (With Current Detection).
- Step 3. Press the entire module onto the rail and slide it until it is in the correct position, then snap the cover into place

## Safety Warning 🔔

- Each relay circuit requires a suitable circuit breaker or fuse. •
- Tightening torque should not exceed 0.4 Nm. .
- Input power wire: Max 4mm<sup>2</sup>; Load wire: Max 1mm<sup>2</sup>. •
- Installation location: Distribution box
- Do not connect the YC-BUS interface incorrectly, as it may damage the equipment.
- The YC-BUS interface must not be connected to AC power; otherwise, it will damage all devices on the bus. •
- Ensure a good ventilation environment.
- Do not expose to rain, contact with other liquids, or corrosive gases.


Packing List

•

• YC-RL.04.20B\*1/User Manual\*1/Certificate of Conformity\*1

| 12345678 ON OFF  |
|--|
| ID01ID02ID03ID04ID05ID06ID07ID08   |
|  |
| ID09 ID10 ID11 ID12 ID13 ID14 ID15 ID16  |
| ID17 ID18 ID19 ID20 ID21 ID22 ID23 ID24  |
|  |
| ID33 ID34 ID35 ID36 ID37 ID38 ID39 ID40  |
|  |
| ID41 ID42 ID43 ID44 ID45 ID46 ID47 ID48  |
| ID49 ID50 ID51 ID52 ID53 ID54 ID55 ID56  |
| ID57 ID58 ID59 ID60 ID61 ID62 ID63   |
|  |
| Figure 7. Address Dip Switch Table 2   |
|  |
|  |
|  |
| WL1 WL2 WL3 WL4  |
| \' \\ \' \\ \' \\ \' \\  |
| <b>* * * * * * * *</b>   |
|  |
|  |
|  |
| ConyCtri   |
|  |
|  |
| READER A DAY AN COMPLEX TWO FOR READER A DAY AND A |
|  |
| lead to the fire   |
|  |
| from the previous module to the next module  |
| to the next module   |

Figure 8. Product Wiring Diagram



#### **Technical support**

Service Hotline: 86-18029750069

working hours: 9:00-12:00,13:00-18:00,From Monday to Friday)
Email:ceshi@easyctrlgz.com

website: http://www.easyctrlgz.com




2025 Guangzhou Easyctrl Intelligent Technology Co., Ltd. All rights reserved This manual may be changed or updated without prior notice.

# **Technical Parameters**

| Basic Parameters            |  |  |  |
|-----------------------------|--|--|--|
| Operating Voltage           | 24VDC±10%  |  |  |
| Maximum Power Consumption   | ≤3.2W  |  |  |
| Rated Voltage               | 250/400VAC   |  |  |
| Output Circuit              | 4-channel relay (built-in mutual inductance coil, accuracy 0.1A)         |  |  |
| Relay                       | Fanhua single-contact magnetic latching relays                           |  |  |
| Rated Current               | 20A (single channel),Surge current capability: 500A/2ms (single channel) |  |  |
| Switching Cycles            | no-load: 1,000,000 cycles , load: 30,000 cycles                          |  |  |
| Protection                  | circuit breaker for each circuit   |  |  |
| External Environment        |  |  |  |
| Operating Temperature       | -5°C~45°C  |  |  |
| Operating Relative Humidity | ≤90%   |  |  |
| Storage Temperature         | -20°C~60°C   |  |  |
| Storage Relative Humidity   | ≤93%   |  |  |
| Product Specifications      |  |  |  |
| Dimensions ( L*W*H )        | 72 mm*102 mm*68 mm   |  |  |
| Net Weight                  | ≤316 g/pcs   |  |  |
| Enclosure Material          | flame retardantPP  |  |  |
| Installation Method         | standard 35mm DIN rail mounting  |  |  |
|                             | (see Figure 9-12)  |  |  |
| Protection Level            | IP20   |  |  |
| Custom Dianuam              |  |  |  |

#### System Diagram





# **Bus Specification**

| Bus interface | 4-core wire : RVV4*0.75 | UTP : CAT5/CAT5E         |
|---------------|-------------------------|--------------------------|
| 24V           | RED                     | BROWN WHITE/BROWN        |
| GND           | BLACK                   | BLUE WHITE/BLUE          |
| А             | YELLOW                  | ORANGE WHITE/GREEN WHITE |
| В             | GREEN                   | ORANGE/GREEN             |